

BETINA

1

2

3


A x1 	B x1 	B1 x1 	C x1
D x1 	E x2 	F x24 	G x24
H x12 	I x4 	J x8 	K x8
L x4 	M x2 	N x2 	O x14
		P x16 	Q x32
		R x8 	S x32
		T x32 	U x4
		V x1 	W x3

HALMAR Sp. z o.o.

ul. Centralnego Okręgu Przemysłowego 2, 37-450 Stalowa Wola, POLSKA / POLAND
tel. +48 15 843 28 10, fax: +48 15 842 19 57, e-mail: office@halmar.com.pl

v.3 **1/2**


BETINA




HALMAR Sp. z o.o.
 ul. Centralnego Okręgu Przemysłowego 2, 37-450 Stalowa Wola, POLSKA / POLAND
 tel. +48 15 843 28 10, fax: +48 15 842 19 57, e-mail: office@halmar.com.pl

v.2
 2/2

BETINA



BETINA



BETINA

